



MOONCANDLES

Goditi le candele senza i problemi della cera e delle fiamme pericolose, come pure la convenienza del telecomando. Le candele senza fiamma sono sicure da usare con bambini ed animali domestici, nonché vicino alle tende, letti ed altri complementi d'arredo. Il telecomando consente di utilizzare le candele senza fiamma in aree difficili da raggiungere come mensole o persino lampadari.

MOONCANDLES A COLORE UNICO

Uso con il Controllo Remoto:

Inizia con l'accendere l'interruttore. Premi il pulsante 'ON'/'OFF' alla base della candela.

Modo – Ci sono due modalità per la luce della candela, luce tremolante e luce fissa. Premi questo pulsante per passare tra questi due modi.

Timer – Quando la luce della candela è accesa, premi '4H'/'8H' per impostare la candela su un 'tempo di combustione di 4 o 8 ore'. Una volta che il tempo è stato impostato, la luce della candela si spegne automaticamente dopo 4 o 8 ore.

Dimmer – Usa i due pulsanti dimmer per variare la luminosità delle candele..

Uso senza Controllo Remoto:

Usa l'interruttore alla base della candela per accendere o spegnere la luce della candela a tuo piacimento.

MOONCANDLES A COLORI MULTIPLI

Uso con il Controllo Remoto:

Inizia con l'accendere l'interruttore. Premi il pulsante 'ON'/'OFF' alla base della candela.

Modo – Ci sono due modalità per la luce della candela, luce tremolante e luce fissa. Premi questo pulsante per passare tra questi due modi.

Timer – Quando la luce della candela è accesa, premi '4H'/'8H' per impostare la candela su un 'tempo di combustione di 4 o 8 ore'. Una volta che il tempo è stato impostato, la luce della candela si spegne automaticamente dopo 4 o 8 ore.

Colori-Multipli :- Premi il pulsante 'Multi Colour' per permettere alla luce della candela di cambiare colore automaticamente. Premi il pulsante di nuovo in modo da fermarti al colore corrente. .

Tasti Colore – Basta che tu prema uno dei dodici tasti colore per ottenere il tuo colore preferito.

Uso senza Controllo Remoto:

Usa l'interruttore alla base della candela per accendere o spegnere la luce della candela a tuo piacimento.



Made in China

Copyright Frostfire Ltd – www.frostfiregroup.com – mail@frostfiregroup.com



Enjoy candles without the messy wax and dangerous flames as well as the convenience of the remote control. Flameless candles are safe to use with children and pets as well as near curtains, beds and other home furnishings. The remote control lets you use the flameless candles in hard to reach areas such as shelves or even chandeliers.

SINGLE COLOUR MOONCANDLES

Use with the Remote Control:

Turn on the power switch first. Press the 'ON'/'OFF' button on the base of the candle.

Mode – There are two modes for the candle light, flickering light and steady light. Press this button to switch between these two modes.

Timer – When the candle light is on, press '4H'/'8H' to set the candle 'burning time' for 4 or 8 hours. Once the time is set, the candle light automatically turns off after 4 or 8 hours.

Dimmer – Use the two dimmer buttons to change the brightness of the candles.

Use without the Remote Control:

Use the power switch on the base of the candle to turn on/off the candle light as required.

COLOUR CHANGING MOONCANDLES

Use with the Remote Control:

Turn on the power switch first. Press the 'ON'/'OFF' button on the base of the candle.

Mode – There are two modes for the candle light, flickering light and steady light. Press this button to switch between these two modes.

Timer – When the candle light is on, press '4H'/'8H' to set the candle 'burning time' for 4 or 8 hours. Once the time is set, the candle light automatically turns off after 4 or 8 hours.
Multi-Colour – Press the 'Multi Colour' button to let the candle light change colours automatically. Press the button again to stop at the current colour.

Multi- Colour : Press the " Multi Colour " button to let the candle light change colours automatically ; press the button again to stop at current colour.

Colour Keys – Simply press one of the twelve colour keys to get your favourite colour.

Use without the Remote Control:

Use the power switch on the base of the candle to turn on/off the candle light as required.

BATTERIES

Should your candles or remote control stop working replace the batteries in the base of the candles or the remote control.

Batteries can be inserted and removed by removing the battery cover at the base of the candle. The remote control uses a CR2025 battery and can be accessed via the sliding cover at the base of the RC.

BATTERY WARNINGS – Do not dispose of batteries in regular household waste streams. Do not get the batteries wet, hot or in contact with flames. Dispose of batteries at your local battery recycler. Do not expose the candles or batteries to heavy rain.



Made in China

Copyright Frostfire Ltd – www.frostfiregroup.com – mail@frostfiregroup.com